



## **ONLY USE DIESEL**

- Check all Oil levels before use.
- Never run out of diesel.
- Change air filter's oil and clean the air filter every 300 hours or sooner depending on environmental conditions.
  - Change fuel filter every 500 hours
- of operation.
- Clean oil filter every 100 hours of operation.
  - Use diesel motor oil SAE 5W30 or
- higher depending on operating temperatures.
- Change oil after the first 20 hours of operation, then change every 100 hours of operations.
- To extend life, run engine Break-in at medium power for the first 10 hours. (refer to owner's manual)

Pro WINCH

CAUTION Diesel Only 1.8in x 3.4in V1.0

## **CAUTION Diesel Only 1.8in x 3.4in** V1.0



**Packaging Weight & Dimensions** 



## **Technical Specifications**

## **Unit Weight & Dimensions**

| Total Unit Weight | 0.1 lbs / 1 Kg | Package 1 Net Weight   | 0.1 lbs / 0 Kg   |
|-------------------|----------------|------------------------|------------------|
|                   |                | Package 1 Width        | 3 in / 7.62 cm   |
|                   |                | Package 1 Gross Weight | 0.1 lbs / 0 Kg   |
|                   |                | Package 1 Height       | 0.5 in / 1.27 cm |
|                   |                | Package 1 Length       | 3 in / 7.62 cm   |